



Busbars

Number	Rated- Operating Current I _e (A)	Features	Utilisation	Designation	Notes Article No.	Units per Package
IEC Busbar Support						
3	630	With snap-in slide for adapting to the respective size of the bar	12 x 5/10 15 x 5/10 20 x 5/10 25 x 5/10 30 x 5/10	BBS-3/FL 107066	With pre- drilled holes inside for screw-fixing	10 units
UL Busbar Support						
3	630	With snap-in slide for adapting to the respective size of the bar	12 x 5/10 20 x 5/10 30 x 5/10	BBS-3/FL-NA 107067	With pre- drilled holes inside for screw-fixing	10 units
If used in feeder circuits according to UL 508A up to 600 V, it is necessary use the BBC-BT-NA base plate in addition.						
End Cover						
–	–	–	To cover the busbar ends for BBS-3/FL and BBS-3/FL-NA	ES-BBS-3/FL 107068		10 units
UL Base Plate						
–	–	To be used when the air gap between fully equipped busbar systems and mounting plate is insufficient	Necessary for UL support BBS-3/FL-NA	BBC-BT-NA 107172	1100 mm long	2 units
PE/N Earth/Neutral Busbar Support						
2	630	With snap-in slide for adapting to the respective size of the bar	12 x 5/10 15 x 5/10 20 x 5/10 25 x 5/10 30 x 5/10	BBS-2/FL 107069	can be mounted individually	10 units
1	630	With snap-in slide for adapting to the respective size of the bar	12 x 5/10 15 x 5/10 20 x 5/10 25 x 5/10 30 x 5/10	BBS-1/FL 107161	can be mounted individually	10 units

VT12706



VT12806



VT14006



VT19806



VT13006



VT17106

