

Gniazda przenośne / Portable sockets



B.1924

16A

3P

IP67



B.1925

32A

3P

IP67



B.1932

16A

4P

IP67



B.1933

32A

4P

IP67



B.1934

16A

5P

IP67



B.1935

32A

5P

IP67



B.1052

63A

5P

IP67



B.1929

125A

5P

IP67

Wtyczki przenośne / Portable plugs



B.1922

16A

3P

IP67



B.1923

32A

3P

IP67



B.1902

16A

4P

IP67



B.1906

32A

4P

IP67



B.1903

16A

5P

IP67



B.1907

32A

5P

IP67



B.1050

63A

5P

IP67



B.1913

125A

5P

IP67

Gniazda stałe / Stationary sockets



B.1936

16A

4P

IP67



B.1937

32A

4P

IP67



B.1938

16A

5P

IP67



B.1939

32A

5P

IP67