

							
Narożnik wewnętrzny	Narożnik zewnętrzny	Łącznik kątowy	Końcówka listwy	Łącznik prosty do pokrywy o szer. 80 mm	Łącznik prosty do pokrywy o szer. 110 mm	Łącznik podstawy	Spinka kablowa ^(*)
3302 12	3302 11	3302 13	3302 14	3302 15	–	3302 16	3302 18
10	10	10	10	50		10	20
3302 72	3302 71	3302 73	3302 74	3302 15	–	3302 75	3302 18
1	1	1	1	50		1	20
3302 22	3302 21	3302 23	3302 24	3302 15	–	3302 25	3302 18
8	8	4	10	50		10	20
3302 32	3302 31	3302 33	3302 34	–	3302 35	3302 36	3302 18
5	5	2	5		25	10	20
3302 42	3302 41	3302 43	3302 44	2 x 3302 15	–	3302 45	3302 18
5	5	2	5	50		5	20
3302 52	3302 51	3302 53 ^(*)	3302 54	–	2 x 3302 35	3302 55	3302 18
1	1	1	2		25	5	20

